

Edison 3
Edison 3 **3G**

Complete User Manual

Edison 3 / Edison 3 3G

The bq team would like to thank you for purchasing your new tablet Edison 3 / Edison 3 3G. We hope you enjoy using it.

With this device you can browse the internet, check your email, play games (which you can download directly onto the device), read e-books, transfer files via Bluetooth®, record audio, watch movies, take photos and videos, listen to music, chat with your friends and family.

About This Manual

- To make sure that you use your tablet correctly, please read this manual carefully before you start using it.
- Some of the images and screenshots shown in this manual may differ slightly from those of the final product.
- Due to firmware updates, it is possible that some of the information in this manual does not correspond exactly to the operation of your device. To obtain the most up-to-date version of this manual, please go to www.bq.com.
- bq shall not be held liable for any issues relating to performance or compatibility resulting from modification of the registry settings by the user. Nor shall it be held liable for any incompatibility issues with third-party applications available through the app stores.

Icon Guide

Danger: This icon indicates situations that could pose a risk to personal safety or health.

Warning: Situations which pose no risk to personal safety or health, but could pose a risk to the correct functioning of the device.

Tip: Additional information to help you get the best out of your device.

Trademarks

The bq logo is a registered trademark of Mundo Reader, S.L.

The Android and Google Search™ logos are registered trademarks of Google Inc.

Wi-Fi® is a registered trademark of the Wi-Fi Alliance.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. .

MicroSD™ and the corresponding logo are registered trademarks of SD-3D, LLC.

HDMI® (High-Definition Multimedia Interface) is a registered trademark of HDMI Licensing, LLC, subsidiary of Silicon Image, Inc.

Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.

All other trademarks are the property of their respective owners. All rights reserved.

Contents

8 BEFORE YOU START
8 Box Contents
9 Product Overview

10 GETTING STARTED
10 Inserting a SIM Card*
11 Inserting and Removing the MicroSD Card
12 Switching the Device On and Off
13 Charging the Device and Transferring Files
15 Setup Wizard

16 DESKTOP
16 Screen Lock
17 Home Screen
18 Extending the Home Screen
18 Adjusting the Screen Rotation
19 Customising the Home Screen
19 Moving and Deleting Icons on the Home Screen
19 Creating Folders
20 Taking Screenshots
20 Making Screen Recordings
20 Learning to Use the Multi-Touch Screen
23 Buttons and Icons
23 Status Bar

* Only on the Edison 3 3G model.

24 Notifications Bar
26 Keyboard

27 PHONE*
27 Managing Contacts
27 Adding a Contact
28 Editing an Existing Contact
28 Using a Contact
29 Create a Group of Contacts
30 Contacts to Display
30 Importing and Exporting Contacts
31 Blocking a Contact
31 Calls
33 Options Available During a Phone Call
34 Hiding Your Caller ID
34 Restricting Calls
35 SMS and MMS
35 Message Settings

37 SETTINGS
37 WIRELESS SETTINGS
37 SIM* Management
38 Wi-Fi
39 Bluetooth
40 Data Usage
41 More...
42 DEVICE SETTINGS
43 Audio Profiles
44 Display
45 Storage
46 Battery
46 Power Save Mode
46 Apps
47 PERSONAL SETTINGS
47 Location
48 Security

* Only on the Edison 3 3G model.

49 Language and Text Input
50 Backup & Reset
51 ACCOUNT SETTINGS
52 SYSTEM SETTINGS
52 Date and Time
52 Scheduled Power On and Off
53 Accessibility
56 Printing
56 About Tablet
56 Developer Options

58 PERFORMANCE SETTINGS
58 Optimising Battery Life
58 Monitoring Battery Usage Information

59 EMAIL
59 Setting Up a Gmail Account
60 Setting Up Other Email Accounts
61 Sending an Email
61 Replying to an Email

62 MULTIMEDIA
62 Camera
63 Photo and Video Settings
66 Preset Image Modes
67 Image Gallery
68 Playing Music
69 Playing Videos

70 APPLICATIONS
70 App Store
70 Apps from Unknown Sources
71 Preinstalled Apps
71 Internet Browser
72 Chat
73 Text Editor, Spreadsheets and Presentations
73 Calendar

74 Maps and GPS Navigation
74 File Explorer
75 Dolby
76 News & Weather (Genie Widget)

77 TOOLS
77 Calculator
77 Clock
78 Sound Recorder
78 FM Radio
79 Voice Search

80 APPENDICES
80 APPENDIX A: OTA Updates
81 APPENDIX B: Technical Specifications
82 APPENDIX C Cleaning and Safety
85 APPENDIX D: Information on Exposure to Radio Waves and SAR (Specific Absorption Rate)
86 APPENDIX E: Disposing of this Product Correctly
87 APPENDIX F: Declaration of Conformity

BEFORE YOU START


Box Contents

Before using your bq device for the first time, please check the contents of the box. If any of the following items are missing, contact the retailer that sold you the device.


- ✓ Edison 3 / Edison 3 3G
- ✓ USB to micro-USB cable
- ✓ Mains charger
- ✓ SIM key (only with Edison 3 3G model)
- ✓ Documentation:


  Quick Start Guide
  Warranty and Safety Manual
  bq Accessories

Product Overview



Product Overview





*Micro-SIM card slot only available on the Edison 3 3G model.
**HDMI connection only available on the Edison 3 model.

Do not attempt to remove the rear cover of your BQ Edison 3 / Edison 3 3G, as this may damage the device.

Do not remove the battery by any means. Removing it may invalidate the warranty.

Do not insert any pointed objects into the opening as this may damage the microphone.


GETTING STARTED

Inserting a Micro-SIM card*


Your BQ Edison 3 3G takes a micro-SIM card. The SIM tray is accessed from the exterior of the device. The rear cover should not be removed under any circumstances.

The following steps will help you to insert the card into your tablet before you start using it.

You will find a SIM key included in the box, together with the envelope containing the device documentation.




Ensure that the device is switched off and insert the end of the SIM key into the hole of the SIM slot.



Place your SIM card in the tray. Make sure it is in the correct position by using the notch on the corner to guide you (see image).



Put the tray back into the slot after mounting the SIM card.



* SIM card slot only available on the Edison 3 3G model.

Inserting and Removing the MicroSD Card


Your BQ Edison 3 / Edison 3 3G has an internal memory that can be expanded to 32 GB using a MicroSD card.

To insert a MicroSD card, follow these steps:

Insert the MicroSD card into the slot, making sure the metal pins are at the bottom and facing backwards (i.e. towards the back of the device).



Push the card in until you hear a slight click, which indicates that it has been inserted correctly. If the card is not inserted correctly, the device may not recognise it and its content will not be available.



To remove the MicroSD card, follow the steps above in reverse, bearing in mind the following recommendations:

a. For safety purposes, switch the device off before removing the MicroSD card.

b. If you need to remove the MicroSD card while the device is switched on, unmount it first to avoid damaging the card and losing any data.


To unmount the card, open the **Settings** menu on your device and go to ***Storage > Remove SD card.***

Push the card in until you hear a slight click to indicate that the card has been released. When you remove your finger, the card will slide partially out of the slot, allowing you to remove it completely.


You can choose whether to store your multimedia files on the tablet's internal memory or directly onto the MicroSD card. Remember that any content stored on the MicroSD card will not be available when the card is removed, and any apps stored on there will no longer function.

Switching the Device On and Off

To switch on your BQ Edison 3 / Edison 3 3G, press and hold down (for a few seconds) the power button located on the side of the tablet.



To switch off the device, press and hold down the power button until a pop-up menu appears, containing a number of different options. Select the **Power off** option to switch your device off completely.



If you press briefly on the power button, the screen will switch off but not the device.


Charging the Device and Transferring Files

Your tablet contains a rechargeable (non-removable) 7000 mAh battery, which is charged via the micro-USB port at the top of the device. A USB to micro-USB cable and mains adapter are provided with the tablet. To charge it, follow these simple steps:

A) Using the mains adapter:

1. Plug the USB cable into the mains adapter.
2. Connect the mains adapter to any standard plug socket (220 V / 50 Hz).
3. Plug the other end of the cable into the micro-USB port on your tablet.





B) Using a laptop or desktop computer:

1. Plug the USB cable into a compatible USB port on your computer.
2. Plug the other end of the cable into the micro-USB port on your tablet.

The battery in your BQ Edison 3 / Edison 3 3G is non-removable. If it is removed by anyone other than our Technical Support staff, your device could be damaged and the warranty invalidated.

Allowing the battery to charge fully is recommended when you charge it for the first time as this will help calibrate the battery meter. Bear in mind that some batteries perform better after a number of full charge/discharge cycles.


The time required to charge your device may vary slightly depending on whether it is charged via the mains adapter or via a computer USB port.

If you connect your tablet to a computer using the USB cable, you can also **transfer** files between the two devices (to/from the internal memory, or the MicroSD card, if one is in use). This will allow you to use, copy or store images, videos, music, text documents, etc. on one or both devices.

You can select the file transfer mode when you connect your bq Edison 3 / Edison 3 3G to a computer. Swipe down using one finger from the top of the screen in order to display the various options for **USB computer connection.** The tablet will be connected as a **Media device (MTP)** by default or you can also connect it as a **Camera (PTP).**

There are a number of ways to transfer files. The steps below will show you how to transfer them via USB:

1. Connect your Edison 3 / Edison 3 3G to a computer using the micro-USB to USB cable supplied. Insert the micro-USB connector into the corresponding port on the device, and the generic USB connector into the corresponding port on the computer.
2. Select and copy the desired files onto your tablet or computer. Remember that you can store them on either the internal memory or on the MicroSD card, if you are using one.




To transfer files in **MTP** or **PTP** mode from your device (and/or MicroSD card) onto a computer running Mac OS and vice versa, you will need to download and install the free **Android File Transfer** app onto your computer: www.android.com/filetransfer/.


Do not disconnect the cable while files are being transferred.

Setup Wizard


The first time you switch on your bq Edison 3 / Edison 3 3G, a setup wizard will help you to configure the basic settings for your device:


- Language
- Wi-Fi network
- Google account
- Location and Google settings
- Device name
- bq Protection Plus














DESKTOP

Screen Lock


Your tablet screen will lock itself after a prolonged period of inactivity. To configure the screen timeout interval, press the **Menu** button, go to ***Settings > Display > Sleep*** and select the desired time interval. To turn off the screen and lock the device manually, briefly press the power button.

To unlock the screen, press (but do not hold down) the power button and the screen will come on, displaying the unlock option. To change the unlock option, press the **Menu** button, go to ***Settings > Security > Screen lock*** and choose from the following options: **None, Slide, Face Unlock, Voice Unlock, Pattern, PIN** and **Password**. For more information on each of these options, go to ***Settings > Security.***

If you forget how to unlock the screen, after various wrong attempts, the **Forgot pattern** message will appear at the bottom of the screen. If you press this message you will be asked to enter the email address and password used to set up your tablet. The screen lock will then be removed.

Your Edison 3 / Edison 3 3G includes a new feature that enables you to lock and unlock your tablet via double tap control. Simply tap any part of the screen twice in quick succession so that it lights up and requests the unlock pattern. When the screen is activated, a double-tap anywhere in the notifications bar will lock and deactivate it.

This feature is disabled by default, so in order to use it you will need to activate it by going to ***Settings > Display > Double tap control.***



Home Screen

The **Home screen** or **Desktop** is the main access route to the tools and apps installed on your device. From here, you can check the status of your device, visit websites, open apps, and much more.



1. **Status and Notifications bar.** Displays the time, the Wi-Fi, 3G (Edison 3 3G model only) and Bluetooth connection status, the sound profile and the remaining battery life. Slide the bar downwards from the left to check your notifications, or from the right to access the quick settings menu.
2. **Google search.** Press the search bar to enter the text you want to search for online. You can also carry out a voice search.
3. **Shortcuts.** These give you quick access to the apps you use most frequently.
4. **Apps menu.** Here you can access all the apps installed on your device.

From the **Home screen** you can also press the Menu button, or touch and hold an empty area of the screen, to bring up the customisation options and settings. These options consist of the following:

- Wallpaper: You can select which image to use as a background for the **Home screen** and extended screens.
- Widgets: You can add different widgets to the **Home screen**. Widgets are small apps or programs whose main function is to provide quick and easy access to the tablet's features, and to display information on various subjects such as the news and weather, etc.
- Settings: This option takes you directly to the device's Settings menu, which can also be accessed via the Notifications bar and the Apps menu.

As well as widgets, you can also add shortcuts to your Home screen that provide direct access to apps, contacts, etc. To do this, go to the Apps menu, touch and hold the app you want to create a shortcut for, and drag it into the desired position onto the Home screen.

Extending the Home Screen

The **Home Screen** has a screen that can be expanded to up to four desktops, which you can customise with shortcuts, applications or widgets. To scroll through the **Home screen** and **extended screens**, simply slide the screen to the left or right using your finger.

Adjusting the Screen Rotation

In some applications, the screen automatically rotates from portrait (vertical) to landscape (horizontal) and vice versa, according to the position of your device. If you want to stop the screen from rotating, press the **Menu** button, go to ***Settings > Display*** and untick the **Auto-rotate screen** option.

You can also activate and deactivate automatic screen rotation via the corresponding option (Auto-Rotate) in the Quick Settings menu.

Customising the Home Screen

You can customise your tablet's **Home screen** and **Extended screens** by using your own images as wallpaper, adding icons, widgets and shortcuts to your favourite apps, etc.

To change the wallpaper or add a widget, press briefly on the background image of the **Home screen** or any of the **Extended screens.** A pop-up window will appear enabling you to choose between **Wallpapers, Widgets** or **Settings.**

If you click on the **Wallpapers** option, you can select your desired image and then press **Set wallpaper** to confirm your choice. If you have selected a large image, you will need to crop it accordingly.

Moving and Deleting Icons on the Home Screen

To move an element on the **Home screen**, press down to detach it from the background, then drag it to the desired position and release. You can also move icons from one extended screen to another by dragging them to the edge.

To delete an icon, drag it to the top of the screen until an **X** and the word "**Remove**" appear. When the icon turns red, release it to delete.

Creating Folders

To create a folder, drag one icon on top of another that you want to store in the same folder. A folder will automatically be created and the icons placed inside it. You can add more icons to the folder by simply dragging them into it. To name a folder (or rename an existing one), press briefly on it and then on the "Unnamed folder" option. You can remove icons from the folder by opening it and dragging them out.

Taking Screenshots

You can take a screenshot at any time by simply pressing and holding the lower volume button and the power button down simultaneously. The screenshot will be automatically saved in the Gallery, in the Screenshots folder. If you are accessing the phone via the computer, go to ***Pictures > Screenshots.***

Making Screen Recordings

Making a screen recording is very similar to taking a screenshot. Press the upper volume button and the power button at the same time in order to start recording, and press them again to stop. The video will be saved in the same folder as the screenshots.

You can also take screenshots and make screen recordings by pulling down the Notifications bar with two fingers and selecting the corresponding option from the pull-down menu.

Learning to Use the Multi-Touch Screen

Your tablet has a capacitive multi-touch screen with five simultaneous detection points. Different movements can be made over these points which are linked to different functions:


Touch. Touch the screen briefly to select an icon, open an app, activate a text-entry box, etc.



Touch and hold. Touch the screen (on either a clear area or on an icon) with your finger and hold for approximately 2 seconds to bring up a menu of available options.




Drag. To move an icon, press and hold down, drag it to the desired position and then release.



Swipe or slide. On the Home screen, slide your finger left or right across the screen to access the extended screens, or slide your finger up and down the screen to scroll through a website, list or menu.



Pinch. Place two fingers on the screen at the same time and move them towards one another or spread them apart to reduce or enlarge an image.



Double-tap. Tap the screen twice in quick succession to increase the zoom. Repeat the action to zoom out again. You can also use it to activate the screen.



Buttons and Icons

Below is a short description of the different buttons and icons, along with recommendations for how to use them.

While you are using an app, you can return to the previous screen by pressing the **Back** button .

You can go to the **Home screen** at any time by pressing the **Home** button . If you press and hold, you will also access the Google Now application.

You can access the options menu for an app by pressing the **Menu** button .

Status Bar


The Status bar contains important information and is always visible at the top of the screen.

Some of the main icons are:

- Battery almost empty.
- Battery charging.
- Battery fully charged.
- Wi-Fi enabled and connected to a network.
- Sound off and vibrate on.
- Sound and vibrate off.
- Aeroplane mode activated.
- Data services enabled (this could be G, E, 3G, H or H+ according to the type of data connection and the transfer speed).
- USB connected.
- Bluetooth enabled.

Notifications Bar

Pull the bar down from the top left of the screen to view the notifications. Delete all notifications by pressing the icon, or delete each one by swiping it to the side of the screen. Pull the bar down from the top right of the screen to view the Quick Settings icons.



The list of options provide quick and easy access to many different settings, such as the screen brightness and connections, etc.

Entre las opciones que podemos activar/desactivar mediante el menú desplegable que aparece al deslizar hacia abajo la parte derecha de la barra superior están:

Battery: Provides direct access to ***Settings > Battery.***

Settings: Opens the general Settings menu.

Wi-Fi: Enables/disables the Wi-Fi connection.

Bluetooth: Enables/disables the Bluetooth function.

Location: Enables/disables GPS on your tablet.

Aeroplane mode: Enables/disables the signal.

Data connection: Enables/disables your data connection.

Data usage: A shortcut to ***Settings > Data usage.***

Audio Profiles: Select from **General, Silent, Meeting** or **Outdoor.**

Brightness: You can select from automatic or manual brightness adjustment and set the desired level.

Auto Rotate: Enables/disables automatic rotation of the screen.

Shutdown: Enables power-off via the pull-down menu.

Lock/Sleep: Activates the screen lock.

Screen record: Makes real-time video recording of what is being shown on the screen.

Time out: Adjust the time interval before the screen automatically switches off.

Screenshot: Take a picture of the screen via the pull-down menu.

Volume: Enables control of the audio volume (**General, Notifications, Multimedia** and **Alarms**).

Sound record: Provides access to the app for making audio recordings.


Cast screen: Enables detection of remote screens for sending images and sound.

You can access advanced settings for certain functions such as Wi-Fi and Bluetooth by touching and holding the corresponding icon on the list.

When automatic brightness is deactivated, you can adjust the brightness level of the screen by sliding your finger to the left or right.

Keyboard

On pressing on any text field, the virtual keyboard will appear.



1. Enable/disable caps lock.
2. Change from letters to numbers and symbols, or vice versa.
3. Space.
4. Enter/line break.
5. Delete.

The keys with "..." in the bottom right-hand corner provide access to additional features when you touch and hold them.

You can find more information on the keyboard settings and languages for text entry via ***Settings > Personal > Language & input.***

PHONE*

Managing Contacts

The **Contacts** application provides access to all of your saved contacts on your SIM card, the internal memory of your device and any online accounts you have set up.

Using this application you can:

- Create new contacts
- Update existing contacts
- Create a group of contacts
- Select the lists to be displayed
- Make phone calls or send SMS
- Blocking Contacts



You can save your contacts in various locations: SIM card, Google account, tablet, etc. The options available will depend on where you have saved your contacts.

Adding a Contact

You can add a new contact manually to your list via the **Contacts** app or via the **Call history.**

To add a contact manually:

1. Open the **Contacts** app via the **Home screen**.
2. Press the  icon and the list of available accounts will appear on screen. You can then save the contact in the desired location.
3. Fill in the fields as desired:
   a. Name and surname
   b. Organisation
   c. Phone numbers
   d. Email
   e. Postal address
   f. Add another field
4. Press Done to save the contact.

* Only on the Edison 3 3G model

To add a contact via **Call history**, press the **Contacts** icon to the left of the number you want to add (pressing directly on the number will call it) and then press the **Create new contact** icon on the right. You can also select an existing contact if you want to add a new number. Then select the account where you want to store the new contact, and fill in the details as described above.

We recommend that you always save contacts to your Google account, so that you always have a backup copy if your device is lost or stolen. This will also give you remote access to your contacts from any other device.

Editing an Existing Contact

1. Open the **Contacts** app via the **Home screen**.
2. Select the contact you want to edit.
3. Press the icon.
4. Press one of the existing fields to edit it, or select **Add another field** to save new information.
5. Press **Done** to save the changes.

Using a Contact

You can use the **Contacts** app to make a call, send a text message or communicate via other channels with the contacts you have added to the list.

Simply press the name of the person you want to contact and select the corresponding option. You can also press on the contact photo to bring up a quick menu. From here you can:

- Make a phone call
  - Press on the number you want to call.
- Make a video call
  - Press the icon and select which SIM card you want to use to make the video call.
- Send an SMS
  - Click on the icon and you type your message.

· Send an email
  - Press on the desired email address.
  - Select the desired email client (Email, Gmail, etc.).
· Other options (press the ⋮ icon in the top right corner)
  - Delete contacts: Delete multiple contacts at the same time.
  - Share contacts: Send information on various contacts.
  - Share: Share this contact with another of your contacts.
  - Delete: Delete the current contact.
  - Contacts to display: Select an account for displaying the saved contacts.
  - Import/export: Select and transfer contacts from one account to another.
  - Accounts: Sync the contacts with another account.
  - Settings: Access the display options.

Create a Group of Contacts

The Contacts app also allows you to create groups, so that you can organise your contacts quickly and easily. For example, you can have different groups for friends, colleagues, family, etc.

To create a group:

1. Select the ▼ icon on your contacts list and press **Create new group.**
2. Enter the group name.
3. Press **OK** to save it and it will appear in the list of groups.

When you save a contact on the tablet, you can set a special ringtone or notification for the entire group so that you can easily recognise incoming calls and messages from members of that group.

Contacts to Display

This is a very useful option that allows you to choose which contacts are shown on your contacts list. Select from those saved to your Gmail account, your phone,your Facebook contacts and other lists.

To do this, follow these instructions:

1. Open the contacts list and press the ⋮ icon.
2. Select the Contacts to display option.
3. Select which contact groups you want to be displayed:
   a. All contacts
   b. Gmail contacts
   c. SIM contacts
   d. Tablet contacts
   e . Customise: Select sub-groups from within any of the previous options (family, friends, etc.)

Importing and Exporting Contacts

This option allows you to copy a series of contacts from one source and paste it onto another account or app or the internal device memory. To do this:

1. Press the ⋮ icon from the contact list.
2. Press on **Import/Export.**
3. Select the location for copying contacts.
4. Select the destination for pasting them.
5. Select the contacts to be copied.
6. Press **OK** to start the process.

Blocking a Contact

1. Open you entry for the contact you want to block by pressing on the image.
2. Press the ⋮ icon to access more options.
3. Tick the Block incoming calls option.

Calls

Press on the phone icon on the **Home screen** to access the call menu. This menu enables you to:

- View the contacts that call the most
- View the incoming and outgoing call history
- Tick the Block incoming calls option

From this menu, you can view your list by pressing All contacts, or by pressing the ⋮ icon followed by **Contacts.**

Press the icon to display your call history, where you can see a chronological list of all the calls you have made and received (ordered by most recent).

There are a number of ways to make a phone call:

Via your list of contacts

1. Access the list by any of the above methods.
2. Press the name of the contact you want to call.
3. Press on the number to call.

Via call history


1. Press the phone icon on the **Home screen.**
2. Press the clock icon.
3. Press on the number or contact name and select the call type:
   - Voice call: For making a voice call.
   - Video call: For making a video call using your data plan.
   - Internet call: For using your data plan to make a VoIP call.

Open the keypad.

1. Press the phone icon on the **Home screen.**
2. Press the icon to display the keypad.
3. Enter the number you want to call.
4. Press the phone icon at the bottom of the screen to call the number you have entered.

When you receive an incoming call, you can choose to answer it, reject it or respond via text message.

When your phone is ringing, the screen will display the phone number calling you and a circle of blinking dots. Choose from the following options:



1. Press the circle and drag it to the left to reject the call.
2. Press the circle and drag it to the right to answer the call.
3. Press the circle and drag it upwards to respond with a text message.

Options Available During a Phone Call


If you have answered the call, the top of the screen will show the caller's name (if stored on your lists of contacts), the phone number (mobile and/or landline), the country they are calling from and the SIM card network in use for this call.

Various options will be displayed at the bottom of the screen during the call:

- Open the keypad.
- Activate the external speaker (useful for hands-free operation).
- Mute the internal microphone.
- Pause the call and place the caller on hold.
- End the call by pressing the red phone icon.

· To add another contact to the call in progress:

- First place the call in progress on hold, and call the contact you want to add.
- When you are connected to the new contact, you will have the option of alternating the conversations or combining them in a conference call.



You can also hide your number for outgoing calls, so that the person you are calling won't see your number.

Hiding Your Caller ID

1. Open the Call menu by pressing the icon on the **Home screen.**
2. Press the icon and select **Settings.**
3. Go to ***Voice call > Additional settings.***
4. Press **Caller ID.**
5. Select the **Hide number** option.

Making a test call is recommended to check that you have hidden your number correctly. Some network operators do not allow hidden numbers and your number may still be displayed on outgoing calls.

Restricting Calls

It might be useful to restrict certain call types from time to time, whether incoming or outgoing. To do this you will need to access the call barring menu:

1. Open the call application by pressing the icon on the **Home screen.**
2. Press the icon and select **Settings.**
3. Select ***Voice call.***
4. Press on **Call barring.**
5. Select the type of calls to be restricted from these options (any restrictions will be applied for all calls, individual numbers cannot be restricted):
   a. All outgoing calls
   b. International outgoing calls
   c. International outgoing calls except to home PLMN
   d. All incoming calls
   e. Incoming calls while roaming

To restrict incoming calls from individual numbers, follow the instructions in the previous section on **Blocking a contact.**

SMS and MMS

To send an SMS (text message), go to **Messaging** via the apps menu or via the shortcut on the **Home screen.**

You can then specify the recipient(s) by entering their name(s) in the To field at the top of the screen or by pressing the icon to the right to select a name from your contact list. If the recipient's number is not stored on your contact list you can type it in directly.

You also have to option to send an MMS (multimedia message). Simply press the **+** icon located on the bottom right. On pressing this icon, a variety of multimedia options will appear for attaching files to the MMS:

- Capture picture
- Capture video
- Record audio
- Contact
- Pictures
- Videos
- Audio
- Calendar
- Slideshow

Text messages are limited to a maximum of 140 characters per message. You can write longer texts which will be sent as a single message, however, for billing purposes, your network operator will treat them as several messages. In contrast, there is no limit to the text you can send with an MMS after attaching the multimedia file.

Once you have added the recipient, the text and the MMS file, simply press the **Send** icon located to the right of the text and your message will be sent.

Message Settings

Via the **Messaging** app you can configure various options for sending and receiving SMS and MMS. Press the icon and go to **Settings:**

- SMS Enabled: Touch to change your default SMS app **Messaging** (by default) or **Hangouts.**
- Text messages (SMS).
  - Delivery reports: Request a message to confirm that your SMS has been received by the recipient
  - Manage SIM card messages
  - Edit quick text: Edit the list of default responses to suit your needs
  - SMS service centre
  - SMS storage location
- Multimedia messages (MMS).
  - Group messaging
  - Delivery reports
  - Read reports
  - Send read report
  - Auto-retrieve
    - National
    - Roaming auto-retrieve
  - Creation mode
  - Size limit:
  - Priority
- Notifications
  - Mute
  - Select ringtone
  - Vibrate
  - Pop-up notification
- General: adjust how messages and chat are displayed within the app.


SETTINGS

WIRELESS SETTINGS

SIM Management*

You can select and deselect the SIM card for phone calls, video calls, sending messages and the data connection. You can edit the SIM name, enter the phone number, set the background colour and the display numbers.

Under **General settings**, you can configure the **Roaming settings** if you use your tablet abroad, as well as the SIM card detection settings.




* Only on the Edison 3 3G model.

Wi-Fi

Before browsing the internet via Wi-Fi, you will need to connect to a Wi- Fi network and in some cases, configure it. To do this, go to ***Settings > Wireless and Networks.***

If Wi-Fi is disabled, move the selector to the right. Press on **Wi-Fi** and your device will automatically search for and display a list of available Wi-Fi networks, which updates automatically.



Press the name of the network you want to connect to, enter the password if necessary and press **Connect to network**. If the tablet connects successfully, **Connected** will appear below the name of the network.

There is a time limit for entering the Wi-Fi password, after which the Wi-Fi will be disabled. Selecting the **Show password** option is recommended before entering the password, to ensure that you enter it quickly and correctly.

When Wi-Fi is enabled, the device will automatically connect to the chosen network. If your device detects a network that has not been previously configured, it will notify you.


To access the **Scan, WPS Pin Entry, Wi-Fi Direct** and **Advanced settings** for the network, go to ***Settings > Wireless and networks > Wi-Fi***, then press the **Menu** button ⋮.

WPS PIN. Depending on the router you are using, this tool enables you to connect to your Wi-Fi network more easily and securely. You can connect and sync your tablet with your router by pressing the icon on your device (or going to ***Menu*** ⋮ ***> PIN WPS*** y en el router el botón físico de PIN WPS.

Advanced settings. Here you can request to be notified when networks are available, adjust the settings for Wi-Fi on sleep mode, optimise battery usage and access the IPv4/IPv6 and MAC addresses (the unique ID numbers assigned to each device).

Bluetooth

To connect to and share files with other Bluetooth devices, you will need to enable it. Go to ***Settings > Bluetooth*** and slide the tab to the right.




To configure the visibility timeout, rename your tablet, show received files or access the advanced settings, press the **Menu** button ⋮.

To connect your tablet to other devices, go to ***Settings > Wireless and networks > Bluetooth*** and select the name that corresponds to your device. Your device will then be visible to other devices for a period of 2 minutes.

To connect to another device, provided that both devices are visible, simply press the name of the device you want to connect to. A pop-up window will appear on your screen with a **Bluetooth pairing request**; accept the request and then synchronise it with the other device. Press Pair on your BQ and confirm on the other device to sync them.

Data Usage

In this section, you can view the statistics of each application for data transfers via Wi-Fi or mobile internet*. Under the **Overview tab**, you will see the data traffic for today and in total, whereas under Wi-Fi or your mobile operator tab*, you can view the data traffic statistics for each application.



More...


Here you can activate **Aeroplane mode**, manage Tethering and the virtual private network (**VPN**) settings on your device.

Aeroplane mode: Selecting this option will disable all wireless connections.

Default SMS app: Determine the application for sending SMS.

Tethering and portable hotspots: First make sure that your data connection service is enabled under **Mobile networks.** Then go to **Tethering** and portable hotspot and enable the **Wi-Fi hotspot.**

* Only on the Edison 3 3G model.



Under **Wi-Fi hotspot > Set up Wi-Fi hotspot**, you can check your device´s SSID network name and view your password (by ticking the Show password box). The same settings must be entered on the device you want to connect to your shared **Wi-Fi network**. You can limit it so that only specific users can connect.

To share your connection via USB, connect your tablet to a computer using the cable and select the **USB tethering** option.

If you want to share your connection via Bluetooth, tick the **Bluetooth tethering** box to enable it. In order to share your device´s network with a computer, Bluetooth must be enabled on both devices.


VPN: This option enables you to configure a virtual private network.

Mobile networks: This option enables users of the Edison 3 3G model to manage the mobile networks. You can enable or disable the modem, enable data via the mobile network, view the APN of your operator, set the connection for data roaming services, limit the use of 2G networks and select a network operator.

DEVICE SETTINGS

Audio Profiles

You can set up the **General** and **Outdoor** (with highest volume and vibrate) profiles.




You can also create a new profile by pressing on the **Add** + button in the top right corner, or you can also reset the default configuration by pressing the **Reset** icon.

Under **General** or any new profile created, you can enable vibrate and select the tone for notifications and alarms. You can also enable or disable sounds and vibration alerts for system features such as: **Dial-pad touch tones, Touch sounds, Screen lock sounds** and **Vibrate on touch.**

You can also adjust the volume for **notifications** or **multimedia** content by pressing the **volume buttons**.

Under **Digital Dolby Plus**, you can **Launch App** to configure the application which is explained further on, or you can select a **Profile.**

Display



Lock screen notifications: Enable or disable this option to display the notifications received on your BQ when the screen is locked.

Wallpaper: Select an image or video to use as wallpaper. You can choose between live wallpaper, system wallpaper or photos from your Gallery or video images.

Brightness: Adjust the screen brightness level.

Auto-rotate screen: Enable or disable automatic screen rotation when turn your tablet sideways.


Sleep: Set the time delay before the screen automatically switches off.

Screensaver: Enable or disable this option.

Font Size: Choose from four different font sizes.

HDMI: Activate the HDMI connection to link your tablet to another device using a mini-HDMI cable. You can also adjust the video output resolution. This option is option available on the Edison 3.

Cast screen: You can use your tablet to send an audio/video signal to a remote screen (another tablet, smartphone, television, etc.) using the Wi-Fi network to display its screen on both devices. The remote screen must be compatible with the Miracast/DLNA protocol in order to do this. Follow these steps to configure your BQ and duplicate your device´s screen:



1. Switch on your compatible device and enable cast screen mode (the process will vary depending on the manufacturer).
2. On your tablet, go to ***Settings > Device > Display.***
3. Scroll down the list and select **Cast screen.**
4. Select the screen that you want to send audio/video from your tablet.
5. After a few seconds you will see your tablet screen duplicated on the other device in real time.

Notification lights: You can set different notification LEDs for different applications, in terms of both colour and the blink speed.

This section enables you to set the colour of the LED for various applications that support customisation.


Simply press on the coloured circle and a pop-up window will appear enabling you to choose a colour and select the desired blink speed.

Double tap control: Your BQ includes a new feature that enables you to lock and unlock your tablet by double-tapping the screen. Simply tap any part of the screen twice in quick succession so that it lights up and requests the unlock pattern. A double-tap anywhere in the notifications bar will also lock and deactivate it.

Storage

Under this menu you can select the **Default write disk** for your device. You can also check the usage of the various storage units, **unmount the SD card** to remove it safely and **erase all data** from the SD card or internal memory.


If you remove the MicroSD card from your tablet and continue to use the device, some of your apps might not function until you reinsert it. Make sure you switch off the tablet or safely remove the MicroSD card (via the Storage menu) every time you remove it or insert it, otherwise the card could get damaged and data could be lost.



Battery

Here you can choose to display the remaining battery life as a percentage next to the meter in the status bar.

You can also view a graph showing battery duration and usage. Press the graph or the individual apps and resources on the list to view specific details on their usage.



Power Save Mode

Enable this mode to obtain better battery duration, which offers sufficient performance for most applications. If you are watching films in HD or using resource-hungry apps such as games with 3D graphic, we recommend disabling it.


Apps

Here you can access all the apps on your tablet: downloaded apps, apps stored on the tablet, apps currently running and a list of all apps (to see these lists, slide the screen left or right). Press the name of an app or resource to find out more.

PERSONAL SETTINGS

Location

Activating this option allows access to your location to apps that request it (such as preinstalled navigation maps). The **Power Control** widget also allows you to activate the **GPS satellites** option, or alternatively, it can be activated by pulling the Notifications bar down with two fingers and selecting the **Location** option.



There are two ways of providing access to your location: **GPS satellites** and **Wi-Fi & mobile network** location.

Under **Mode** you can choose from:


- High accuracy: Uses GPS, Wi-Fi and mobile networks
- Battery saving: Only Wi-Fi and mobile networks
- Device only: GPS only


While the GPS function is always the most accurate, using your mobile network allows for faster positioning, making it easier to start navigating and to change direction.

Under the **Location** menu, you can also view a list of apps that have recently requested location access and the battery usage involved.

Security

Here you can configure your tablet's **Screen lock** (i.e. the type of lock and the owner information to be displayed on the locked screen), activate the **Encrypt tablet** option with a PIN or password to access your device.







Under **Device administration**, you can view or deactivate administrators, and enable or disable installation of apps from unknown sources (to find out how to install such apps, see the **Apps** section of this manual). You can also manage the **Credential storage**, view trusted CA certificates and install certificates from your SD card.


Language and Input

Here you can set up the system language, activate spell checker and personal dictionary. You can also configure the keyboard, text input methods, voice typing and pointer speed.




The advanced settings for each method enable you to select options such as Vibrate or Sound on keypress.





Backup & Reset

Here you can back up your app data and settings, Wi-Fi passwords, etc. on the Google data servers. (To back up your data, a Google account must be configured on your device).




You can also carry out a factory data reset and delete all pending DRM (digital content protection) licences if you have already deleted the corresponding files.

Carrying out a factory data reset will erase all the data on your tablet's internal SD and remove any additional programs and apps installed. Making backup copies of all your multimedia files is therefore recommended before restoring the factory settings.


ACCOUNT SETTINGS

Here you can choose which email accounts (POP, IMAP or Exchange) you want to sync with your tablet. To add a new account, press the **Add account** icon. Choose from Email, Corporate (linked to a Microsoft Exchange server) or Google. Set up the account by following the instructions that appear on the screen. Then press on the email address to sync your email, contacts, calendar and other options (provided that syncing is permitted by the service provider).



SYSTEM SETTINGS

Date & time



Automatic date & time: Adjust the time automatically based on location information or mobile network. Disabling this option will activate manual date and time configuration.

Automatic time zone: This option lets you enable/disable the automatic time zone provided by the network. Disabling this option will automatically activate the Select time zone option for manual configuration.

Use 24-hour format: Enable/disable the 24-hour time display format.


Choose date format: Select the format for displaying the date.

Scheduled Power On & Off

Enables you to set times and days to automatically switch your device on or off.

Accessibility

Here you can access certain system services to facilitate access to the device, such as large text, spoken word, physical buttons as virtual buttons, spoken passwords, quick boot, etc.



Your tablet also includes the TalkBack app, which offers spoken feedback and visual settings specially designed for visually impaired users.

When you open the app for the first time, a tutorial will guide you through the basic settings:

Speech volume: Adjusts the volume of speech in relation to multimedia volume.


Use pitch changes: Enables/disables the use of lower tones when a key is pressed.

Keyboard echo: This option speaks typed keys aloud. Speech is enabled/disabled when the screen is switched off.

Speak when screen is off: This option enables/disables voice notifications when the screen is off.

Proximity sensor: Enables/disables the proximity sensor to turn off speech whenever you want.

Shake to start continuous reading: Enable the continuous reading function by shaking your device.



Vibration feedback: Enables/disables vibration feedback when an option is selected.

Sound feedback: Enables/disables sound feedback when an option is selected.

Focus speech audio: Enables/disables the option to reduce multimedia volume during a conversation.

Sound volume: Adjust the sound volume in relation to multimedia volume.

Explore by touch: Enables/disables the touch explore feature which allows you to navigate through your tablet using gestures, by pressing once to select and twice to accept.

Automatically scroll list: Enables/disables automatic scrolling of lists.

Single-tap selection: Enables/disables the option to select with a single tap, when the option has been selected beforehand.

Launch 'Explore by touch' tutorial: Launches the tutorial for touch navigation.

Manage gestures: Modify and configure a range of gestures in order to access various accessibility options.

Manage customised labels: Edit the contents of your custom labels.

Resume from suspend: You can specify whether the program resumes when the screen is activated, when the screen is locked or only via the Notifications bar.

Developer settings: Settings for developers and advanced users.

Captions: Enables you to configure the captions. Standard options are:

Language: You can specify the language you want to view them in.

Text size: You can increase or decrease the font size.

Caption style: You can select the default style or you can customise them.

Magnification gestures: This function enables you to zoom in or out of the screen. The following gestures are available:

To zoom in, triple-tap the area you want to magnify.

To zoom out, triple-tap the magnified area.

To move normally around the screen, slide a finger left or right.

To scroll freely, slide two or more fingers across the screen.

To decrease the zoom, pinch the screen with two fingers or spread them apart to increase it.

To expand the content temporarily, triple-tap the area you want to expand and move around the page without lifting your finger off the screen.

Magnification will not affect the keyboard.

Large text: Enables/disables magnification of the system font size and the font size for apps to facilitate viewing of content.

Power button ends call: Enables/disables the option to end a call by pressing the power button.

Auto-rotate screen: Enables/disables automatic screen rotation when the screen is placed in a horizontal position. This option is not activated via the Home screen and the native Apps menu.

Speak passwords: Enables/disables the option to speak passwords when the TalkBack service is activated.

Accessibility shortcut: Using YES/NO commands, you can enable or disable direct access to accessibility features by pressing the power button until you hear a sound or feel a vibration. Then touch and hold the screen with two fingers until a confirmation is received.

Text-to-speech output: Direct access to options for text-to-speech output. To adjust these options, go to ***Settings > Language and text input > Text-to-speech output.***

Touch & hold delay: Configure the time delay between pressing and holding an option and displaying the corresponding options. You can choose Short (default), Medium or Long.

Printing

Android 4.4 comes with wireless printing included as standard and the application also allows you to connect your printer to the internet (check compatibility with your printer manufacturer). This feature lets you wirelessly sync the printer with your smartphone, tablet or computer and print your documents from any location.

About tablet

This section displays the status of the device (battery, network, serial number, etc.), legal information, Android version, model number, baseband and kernel versions and the build number. You can search manually for updates (for more information on firmware updates, see APPENDIX A at the end of this manual).


{ } Developer options


This section is only intended for advanced users, as it contains settings that are useful for app developers. These settings should not be modified if you are not an advanced user.


The menu includes various options, such as:


- Take bug report
- Stay awake
- Process stats
- USB debugging
- Allow mock locations
- Force GPU rendering
- Show CPU usage
- Background process limit

The **Developer option**s menu is hidden in Android by default. To enable it, go to ***Settings > About tablet*** and press the last option (Build number) repeatedly until a message appears to say that you have correctly enabled it. You will then be able to access these options via the main **Settings** menu.









PERFORMANCE SETTINGS

Optimising the Battery Life

You can prolong the battery duration by disabling features that you don´t need. You can also can control how the application and system resources consume battery power. To optimise the configuration pressing **Menu** and going to **Settings.**

- If you are not using Wi-Fi, Bluetooth or GPS, you can configure it under **Settings**, as explained earlier.
- Any **Maps** and **Navigation** apps that you are not using should be closed, as they require GPS access and consumer more power.
- Set your display brightness to **AUTO.** You can access these settings directly by pulling down the Notifications bar with two fingers.
- Set a time delay before the screen goes off under ***Settings > Display > Sleep.***
- Disable the auto-sync feature for certain apps, by going to ***Settings > Accounts.*** Note that you need to sync your email accounts manually, and you will not receive any notification when updates becoming available.
- Switch to **Aeroplane mode** by holding down the power button until a window displaying this option appears, or go to Settings then Network to select it.
- You can also enable Power save mode via the **Setting** menu, so that the standard CPU performance is reduced, offering adequate performance for most situations. Disable this option so that the CPU runs at maximum performance if you are playing games with 3D graphics or watching films in HD.

Monitoring Battery Usage Information

To optimise your battery configuration, go to ***Settings > Battery.*** The list at the bottom of the screen shows battery use for the various apps and services. Press the graph to access more detailed information. The screen showing use details for some apps also has buttons with recommendations on how to adjust your settings for maximum energy saving.

EMAIL

Setting Up a Gmail Account

You will need to set up a Gmail account the first time you switch your device on or whenever you carry out a factory data reset (deleting all data).

If you don´t have an account already, the system will ask you to set one up to access certain features of the device. If you already have an account, you can use it for this initial setup process.

Some apps will not be available until you have correctly set up an account.


From within the app (which can be accessed via the Apps menu) you can access your inbox and configure a variety of different settings, such as how emails are displayed, how you can read and reply to them, and the notifications you receive. You can also group several different accounts together, so that you can receive emails from different addresses at the same time.

Setting Up Other Email Accounts

The Email app allows you to send and receive emails from any other accounts you may have, regardless of provider. This app can be accessed via the Apps menu, or through the **Home screen.**

When you open this app for the first time you will be asked to enter an email address and password, as shown in this image.

1. Enter your email address, then press **Next.**
2. Configure the account settings (syncing, notifications, etc.).
3. You can give the account an alias in order to identify it more easily.
4. Once the configuration is finished, syncing may take a few minutes to bring up all the emails on screen.



Sending an Email

1. Open the **Email** app and press **Compose** .
2. Enter the recipient´s email address, the subject and body of the message.
3. Press **Send** .

To attach files, or add extra recipients (CC or BCC), press the icon and select the corresponding option from the list.

Replying to an Email

You can reply to an email by using one of the following three options:

- **Reply:** Only the person that sent the last message will receive your reply.
- **Reply all:** All the users listed as recipients of the last email will receive a copy of the answer.
- **Forward:** You can send forward a copy of an email to a different user.


The forward option on some email clients only allows the attached files of the previous email to be sent.

MULTIMEDIA

Camera

Your tablet has a front and a rear camera. To enable them, go to ***Menu > Camera*** or directly access the camera from the Home screen. To switch from one to other, press on the corresponding icon at the top right of the screen. Both cameras capture images and videos with different resolutions, with those of the rear camera being higher. The rear camera also has autofocus and flash.





To select from image or video capture, press the camera icon and select the camera or the video icon. To change the settings of the camera enabled, press the first icon . The shutter release is the blue circle, which turns red when the video camera is enabled.

One of the default shooting modes is not available when the using the front camera.

Photo and Video Settings

To use the **zoom** function while taking photos or recording video, use the pinch gesture on the screen before pressing the shutter release or commencing recording. By pressing the > icon, you will access the general settings and an icon to enable the front or rear camera:

Exposure: Adjust the level of image contrast from 3 to -3. The default value is 0.

Colour effect: Add effects to your multimedia files.

Scene mode: Adjust the settings according to the current light conditions.The default setting is Auto.

White balance: Choose from seven types of light setting. The default setting is Auto.

Depending on the option selected, on pressing the **Settings** icon in the bottom right corner, a pop-up window will appear enabling you to adjust general, photo and video settings:

· General settings

GPS location info: Enable this option to add information on where your multimedia file was created.





Image properties: Set the sharpness, hue, saturation, brightness, and contrast levels at Low, Medium or High. The default setting is Medium.

Anti-flicker: Adjust the setting to eliminate moiré or flickering effects or you can also disable it.

Restore defaults: Restore the factory settings of the camera.

· Photo settings





Zero shutter delay settings: Enable/disable image stabilisation.

Face detection: Enable/disable automatic face detection.

Smile shot: Enable/disable automatic smile detection shooting mode.

HDR: High Dynamic Range is a photo mode that increases the image contrast by taking 3 shots with different exposures and superposing them onto one image.

Self timer: Adjust the countdown timer (2s, 10s or disabled).

Continuous shot: Set the number of shots taken if you hold down the shutter release continuously(40 or 99 shots).


Picture size: Set the image quality by choosing values ranging from QVGA up to 5 Mpx.

Preview size: Adjust the size of images in preview mode. Select from Full screen or Standard (4:3).

ISO: Select the level of light sensitivity according to the current conditions. Select Auto mode or you can manually set the values from 100 to 1600.

Face beauty: Select the default Face beauty mode and it enables you to select various options.

· Video camera settings



EIS: Enable/disable video stabilisation.

Microphone: Enable/disable audio recording.

Audio mode: Select Normal or Meeting (to record voices from points at various distances from the device). The microphone must be enabled in order to change the mode.

Time lapse interval: Set the time interval between each frame captured from 1s to 10s. Think of it like this; every second of fast-camera video will require 30 frames. The faster you want the frames to move, the smaller the time interval you will need to select.

Video quality: Select from four video quality options.

Preset Image Modes

On the left side of the screen you will find shortcuts to the different default modes. You can scroll through the list by sliding your finger up and down. One of the key options is panoramic mode which enables you to capture panoramic shots at different angles.

Press the Panoramic icon and a progress bar will appear, to indicate how far you can pan your camera. You can make panoramic shots both horizontally and vertically. As you pan your camera across, an arrow will guide its movement so that the different shots blend into one another to create the panoramic image. Once the progress bar is full (i.e. nine sequential photos have been taken), the panoramic image will be automatically created and saved. You can also make a panoramic image from less than nine images by simply pressing the Tick icon when you have finished panning the camera.

Image Gallery

To view the images and videos stored on your device, press the **Gallery** icon located on the **Home screen.** (It can also be accessed from within the Apps menu).

The main screen of the **Gallery** allows you to browse the images and videos stored in the various different locations on your tablet.

Press a folder to access its content. Press on an image to view it. To view a video, press on it and the **Video player** will open.

You can also access the Gallery directly after taking a photo or recording a video, by pressing the thumbnail of the photo or video that will subsequently appear in the top right corner of the screen.

While you are viewing an image you can also access the following options:

- Press the **Menu** button or the icon ⋮ to display the following options: **Delete, Slideshow, Edit, Rotate left/right, Crop, Set picture as, Details** and **Print.**
- Press the icon to display a list of various apps and social networks through which you can share the photo or video.
- Press the icon to open the image editor to add filters, frames and adjust the brightness, etc.

To zoom in on an image, simply double-tap the screen to magnify it and double-tap again to return to its original size. You can also pinch to zoom by spreading your fingers apart to zoom in, and moving them together to zoom out.

By default, Android does not allow new folders to be created within the Gallery or files to be moved from one folder to another. However, there are some free third-party apps that allow this, as well as other features. An example is the file explorer preinstalled on your tablet which can be accessed via the apps menu.

Playing Music

Your tablet comes with a preinstalled audio player, enabling you to play your favourite music and audio tracks. It is also integrated with the app store so that you can buy and download new music and play whenever and wherever you like.

There are two ways you can load music onto your device:

- Connect your tablet to your computer in Mass storage mode and transfer the music to the internal memory. To do this, simply connect the tablet to the computer using the supplied USB cable, copy the files from your computer and paste them into the Music folder in your tablet's internal memory (you can also store the music on a MicroSD card if you are using one).
- Open the Play Music app and go to the Play Store (the icon located in the top left-hand corner on the main page). In the Store you can search for and browse a large quantity of artists and songs, purchase them and add them to your own music collection.

Once you have downloaded the music onto your tablet, you can find it by going to the main menu in the Play Music app and selecting the **My music** option. You can organise your music by genre, artist, album or song list.



The artist, album and other information used by the app to create the playlists can also be modified using your computer. Right-click on the file you wish to edit, then select ***Properties > Details*** in the pull-down and pop-up menus, respectively.

You can also conduct a keyword search within your music library in order to locate all the albums, songs, etc. that match the description you have entered.

Once you have selected a song, simply press it and a bar will scroll across the screen displaying information about the song currently playing. To open the panel of player options, press the bar located at the bottom of the screen. This panel gives you options such as continuous playback (press the icon on the left to play the list of selected songs again when it has finished), repeat the last song, pause, skip and random.

On this screen you can also use the  and  icons to rate the song. You can also press the icon (located in the top right corner) to access more options, such as adding the current song to an existing playlist or creating a new playlist.

The main screen of the Play Music app also contains the Playlist option, where you can find all the playlists previously created, and the  icon to show a list of the songs you have liked.

Playing Videos

Your tablet comes with a preinstalled video player. It gives you a list of all the videos stored on your device, and allows you to play them, edit them, and much more.

After opening the app you will see a list of available videos. If you press your chosen video, it will start playing automatically. On the bottom right of the screen, you will find an icon that lets you select viewing options such as zoom, original aspect ratio, full screen (stretching the image) and full screen (cropping the image).

Pressing the bar at the top of the screen also allows you to share the video via other apps, play the video on a loop and edit it. The Edit option lets you choose where the video starts and ends; press **Save** to store the edited file

APPLICATIONS


App Store

The App store gives you access to a huge range of programs, games, music, movies, books, and more. Each category contains further sub-categories to help you find exactly what you are looking for.

Important: Be aware that not all downloads are free, and additional costs may be incurred. For paid downloads, the price will appear next to app description, and you will be asked to confirm before downloading to avoid being charged unintentionally.

Apps from Unknown Sources

Occasionally you might want to download apps and/or games from an alternative app store, or directly from a website. In order to install these apps, which generally do not have an electronic signature, you will need to instruct the system to accept apps from unknown sources. Go to ***Settings > Security*** and tick the **Unknown sources** option, then press OK after reading the security warning. Remember to only install apps from trusted sources.



To install apps you have downloaded from outside the App store, you must be able to access the *.apk file on your device. These types of apps have often been compressed using a program such as WinRAR, which means the downloaded file is a *.rar file and will need to be unzipped using a computer, or a file management program such as **ES File Explorer** (already installed on your device).

Upon opening the *.apk file, the system will ask you to confirm installation of the app. Accept and the app will then be installed.

Preinstalled Apps

To access the list of preinstalled apps, press the icon on the **Home screen.** You will then see all the apps installed on your device.

Internet Browser

Using your browser, you can open multiple URLs in different tabs simultaneously. Press the icon to select an active tab or create a new one. When you open a new tab, you can enter a URL manually or you can follow suggestions in the centre of the screen, which are based on the pages you visit most frequently.

Go back/forward ← → : This option lets you return to websites you have recently visited, and move forward again to the most recent page you viewed.

Reload page : Update the current page to refresh its content.

Add bookmark/favourite ☆ : This option lets you bookmark a page so that you can easily return to it later. Bookmarks can be grouped into folders.

Enable voice search : Enable voice recognition in order to perform a Google search automatically.

To close a tab, simply press the tab icon and then press the ✕ symbol on the tab you want to close.

Press the **Menu** button ⋮ to access the following options:

- **New tab:** Opens a new tab so you can browse different websites at the same time.
- **New incognito tab:** Browse the internet in a private tab that is not be stored in the browser history.
- **Bookmarks:** Access the list of saved bookmarks.
- **Recent tabs:** Access the list of recently-closed tabs and restore them if desired.
- **History:** Provides a chronological list (most recent first) of the websites you have visited.
- **Share:** Enables you to share the current page with other users.
- **Print:** Enables you to print the current page to a compatible wireless printer.
- **Find in page:** Search for a specific word or phrase on the current page.
- **Add to home screen:** Select a page to appear as your home page on opening the browser.
- **Request desktop site:** By ticking this box, you will be able to view a website exactly as you would on a computer and eliminate special versions for mobile devices.
- **Settings:** Provides access to the basic and advanced browser settings.
- **Help & feedback:** This option allows you to view feedback from other users, give your own opinion and access the Help section.

Chat

The instant messaging app allows you to configure your email address and telephone number so that you can chat with your contacts. You can also set this app as the default choice for sending SMS.

Text Editor, Spreadsheets and Presentations

With this management tool you can create and publish documents, spreadsheets and presentations. You can also sync the application with Drive account, save your files in the cloud and access them remotely via any compatible device. It is compatible with Word, Excel and PowerPoint, and it also reads PDF files. From this application you can also directly attach files to emails.

Calendar

With the **Calendar** tool you can manage your daily tasks and sync them with your email account so that you can share appointments, meetings and events with your contacts. It also enables you to set up reminder alerts and notifications so that you never miss an appointment. The app also allows you to sync your calendar so you can view it from any other mobile device.

You can create a new event by going to the ⋮ icon at the right top or by selecting the icon + that appears when you press on any free day in the calendar. You can specify the date and time of the event, the location, the people invited, enable and disable alerts, add a description of the event and even configure the availability status that will be shown while you are attending the event.

Maps and GPS Navigation

Your tablet has a preinstalled **Maps** app which enables you to find your current location on the map (for greater accuracy, activate the system GPS), view satellite images or even an actual view of a given location. You can also use the search option to get directions from your current location, either on foot or by car. It also provides a location service to identify affiliated companies and establishments.

Bear in mind that none of the above information (including the maps) is preloaded onto your device; therefore, whenever you use the navigation feature, the tablet will need to access your data connection, which could have cost implications depending on your network operator's mobile price plan and tariffs.

Important: The Edison 3 3G does not have this type of connection, to obtain it you will need wireless connectivity via an external device (for example a smartphone or USB router, which are not provided with your tablet).

File Explorer

This app allows you to explore the folders stored in your internal memory and on the MicroSD card, if in use. It also allows you to copy and move files from one folder to another, unzip compressed files and extract their content, without the need to connect your tablet to a computer. Additionally, you can rename files and create new files and folders.

You can hide certain multimedia folders so that they are not shown in the **Gallery**. To do so, open the **File explorer,** go to the folder you want to hide and, from within the file path, press the New icon +, select the **File** option, name the new file ".nomedia" and press OK to finish. You can access the hidden file and its contents via the **File explorer** app whenever you like. If you want to reverse the process and show the folder in the **Gallery**, simply delete the ".nomedia" file you created previously.

Dolby

To access the **Dolby** app and improve your tablet's audio, go to ***Menu > Dolby.***

You can choose any of the four preset modes from within the app, or select them directly by going to ***Settings > Audio profiles > Profile*** and choosing between **Movie, Music, Game** and **Voice.**

After selecting a mode you will be a shown a graphic equaliser, where you can directly adjust the audio settings by moving the equaliser tabs with your finger. Alternatively, you can choose one of the smart equalisers: ***Open, Rich, Focused*** and ***Customise***. If you adjust any of the modes manually, an icon will appear next to the name of the **Smart equaliser** you have selected (or next to the words **Graphic equaliser:** Custom if you have not selected a smart equaliser). Pressing on this icon will restore the initial values and delete any manual settings you have selected.

Enable the ***Volume leveller*** function to provide a constant level of volume for all content and apps, in accordance with the volume setting defined by the tablet's physical volume controls.

Enable the ***Dialogue Enhancer*** function to make voices sound clearer when playing any multimedia content.

Enable the ***Surround Virtualiser*** function to generate a realistic surround sound effect, compatible with all stereo speakers or headphones (this function will only work with headphones or external speakers, not with the phone's own speaker).

When enabled the **Dolby** icon will be displayed on any video or music players you have installed. You can deactivate the app by pressing the icon.

If you use any other apps that have their own equaliser, the Dolby app will be automatically deactivated in order to prevent any conflict between the two equalisers.

News & Weather (Genie Widget)


This app offers services such as real-time weather information, international news headlines, etc. Your Home screen can hold up to three different widgets, allowing you to access information quickly and easily. These three widgets include both weather and news; you can choose to display them both simultaneously if you want.

For more information on how to add widgets to your tablet, see the section on customising your **Home screen** in this manual.

TOOLS

Calculator


Your tablet's tools include a practical calculator, which enables you to make basic as well as scientific/advanced calculations.



Clock

Go to *Menu* > *Clock* and you will find the **Alarms** option, where you can manage all your alarms.

You can set up different alarms at the same time, and adjust settings such as the name of the alarm, the number of times it sounds, which days of the week it is repeated, the alarm tone and whether it vibrates when the alarm sounds.



You can create new alarms and delete them as often as you want. To temporarily enable or disable an alarm (without deleting it), simply slide the icon located to the right of the alarm time over to the left.

The **Clock** app also allows you to view the local time in any location around the world, and contains other useful functions such as a fully configurable timer and a stopwatch with interval feature.

Sound Recorder

Another of the tools installed on your tablet is the **Sound Recorder.** This app enables you to record audio with ease, selecting from high or standard voice quality and ***Normal***, ***Meeting*** or ***Lecture*** recording modes.

To start recording, simply press the red icon located in the middle of the top part of the screen. The counter and gauge in the centre of the screen will then be activated. Use the icons at the bottom of the screen to pause or end the recording. After you have finished recording, you will be asked if you want to save or delete the audio file. If you decide to save it, you can access it again (with any other recordings you have made) by pressing the icon.

FM Radio

You will also find an **FM Radio** under the apps menu.

This app allows you to listen to your favourite radio programmes, and you can even record and store a broadcast on your internal tablet memory. To tune in the transmitter and move the dial, slide your finger over the dial to search manually, or press the buttons to scan automatically. You can also search all the available frequencies by pressing **More options** then **Scan.**

You can select your favourite stations by pressing the designated icon. Once they are saved as **Favourites**, you can also press and hold to edit the name so that you can find them more easily on the list.

The headphones must be connected to your device to be able to use the radio application, as the headphones themselves serve as the antenna.

From the **More options** menu ⋮, you can select the **Speaker** option so that the audio is played via your computer speakers instead of the headphones. You can also select the **Start Recording** option that enables you to save the current broadcast on your device.

Voice Search

On the **Home screen** there is a widget containing a microphone icon, which will launch the Voice search app when pressed. This app allows you to quickly find information on any subject you search for, and gives you quick access to other apps, such as maps.

APPENDICES

APPENDIX A: OTA Updates

OTA stands for “Over the Air”, which refers to the way that firmware updates are sent to your device; i.e. via your data connection, with minimal intervention required on the part of the user and without the need for complex update procedures.

You device will periodically check for new updates to the operating system, which usually include performance improvements or additional features for your tablet. When the system detects that an update is available, a pop-up window will notify you of this and will request confirmation to install it. Using a Wi-Fi connection to download the update package is recommended.

The system will guide you through the installation process, to ensure that it is completed as quickly and conveniently as possible.

You can also check for updates manually by going to ***Settings > About tablet > System updates > Update.*** A message will appear to tell you that the system is searching for available updates. If an update is found, the installation process is the same as described above.

APPENDIX B: Technical Specifications

You can find all the technical information for your device by visiting this link and selecting the corresponding model: www.bq.com/gb/tablets-prices-sale.html

You can find all the technical information for your device by visiting this link and selecting the corresponding model:

In the table you will find information on the following:

- Dimensions and weight
- Screen
- Internal memory
- Processor
- Battery
- Operating system
- Connectivity
- System functions

APPENDIX C Cleaning and Safety

Cleaning

Before cleaning your device, make sure you have switched it off and disconnected all cables. After cleaning, make sure the screen is completely dry before reconnecting any cables and switching the device back on. Do not use any liquid or spray cleaner directly on the surface of the screen or the casing.

Screen: Use a clean, soft, lint-free cloth to remove dust and dirt from the screen. To remove fingerprints and marks, you may apply a small amount of mild cleaning product to the cloth.

Casing: Use a soft cloth with a small amount of mild cleaning product. After cleaning, rinse the cloth in clean water, wring it out thoroughly and wipe the casing to remove any leftover cleaning product.

Safety

To reduce the risk of an accident, follow these safety instructions:

- Do not use power cables, connectors or plugs that are damaged or contain loose wiring. Do not bend or damage the power cable. Do not touch the power cable with wet hands. Do not pull on the cable to unplug the charger.
- Do not use the device while it is charging. Do not touch it with wet hands.
- Do not hit the charger or cause it to fall. Do not charge the battery using chargers that have not been approved by the manufacturer.
- Do not use the device during electrical storms. Handle and dispose of the battery and charger with caution.
- Do not handle Li-ion batteries that are damaged or leaking.
- Do not use the device in the vicinity of a pacemaker. If possible, try to use it at a distance of at least 15 cm from the pacemaker, as it could interfere with the pacemaker's operation.
- Do not use the device in a hospital or in the vicinity of any medical equipment that may be susceptible to radio frequency interference.
- If you regularly use medical equipment, make sure it is protected against radio frequency interference. If you wear a hearing aid, consult the manufacturer with regard to potential interference.

- In potentially explosive environments, switch the device off. Always observe the site regulations, instructions and warning signs ⚠.
- Do not use the device in refuelling areas (e.g. petrol stations) or in the vicinity of flammable and/or explosive chemical products ⚠.
- Do not store or transport flammable liquids or gases or explosive materials in the vicinity of the device or any of its parts or accessories ⚠.
- Switch off the device upon boarding an aeroplane. The electronic components of a motor vehicle may malfunction as a result of radio frequency interference from the device.
- Prolonged exposure to high levels of sound pressure may cause permanent damage to hearing. It is recommended that you do not wear headphones while cycling, running or walking through areas with heavy traffic or excessive noise.
- Use of the device while driving: Some car manufacturers prohibit the use of mobile devices in their vehicles unless they are equipped with a hands-free kit and external antenna. Ask the vendor of your vehicle whether your mobile device or hands-free Bluetooth kit will interfere with your car's electrical systems. Always devote your full attention to the road while driving and respect the local regulations and laws on the use of wireless devices while at the wheel.
- Location/GPS-based functions: Location-based functions are offered "as is" and "for all corresponding effects". Mundo Reader, S.L. does not claim or in any way guarantee the accuracy of any location-based information.
- When the device is using location-based information, it may suffer from interruptions or failures and its dependence on network availability will increase. Note that functionality may be reduced or obstructed in certain areas, such as inside buildings or in areas close to buildings.
- Use the GPS function with caution, to make sure you are not distracted while driving.
- Antenna: Use of the device with an antenna other than that supplied by Mundo Reader, S.L. may damage it, impair its performance and generate SAR levels (see Appendix D) that exceed the limits established by law. Do not cover the antenna with your hand.

· Aeroplane mode: Use of Bluetooth and WLAN functions may be prohibited on aeroplanes and in other places where radio transmissions are not permitted. Ask for permission before enabling the Bluetooth or WLAN functions, including in Aeroplane mode.


Warning!

This product must be used with a power supply with the following specifications:

INPUT: 100-240 V ~ 50/60 Hz 0.3 A máx.

OUTPUT: 5.0 V ⎓ 2.1 A

Polarity must be as indicated as follows:



Micro-USB

Pin 1 “+”

Pin 5 “-”

The use of power sources other than the ones indicated may damage your device and pose a risk to the safety of people and property.

APPENDIX D: Information on Exposure to Radio Waves and SAR (Specific Absorption Rate)

The design of this tablet complies with the current regulations governing exposure to radio waves. These regulations are based on scientific guidelines that include safety margins designed to ensure the safety of everyone, regardless of age or state of health.

The guidelines on exposure to radio waves use a unit of measurement known as the SAR (Specific Absorption Rate). SAR tests are carried out using standardised methods, with the tablet transmitting at the highest certified level of power on all the frequency bands it uses.

The maximum SAR levels recommended by the ICNIRP (International Commission on Non Ionizing Radiation Protection) is 2 W/kg, measured on 10 g of tissue.

The highest SAR levels recorded for this tablet are as follows:

	Edison 3	Edison 3 3G
When used in direct contact with the body	0,790 W/kg (10 g)	1,161 W/kg (10 g)

This device complies with the guidelines on exposure to radio frequency both when it is used in the normal position next to the ear and when it is positioned at least 1.5 cm from the body. In order to send data files or messages, this device requires an adequate network connection. On certain occasions, the transmission of data files or messages may be delayed until an adequate connection becomes available. Until the transmission has been completed, make sure you follow the instructions on the separation distance mentioned above.

APPENDIX E: Disposing of this Product Correctly



(Electrical and electronic waste).
(Applies within the European Union and in European countries with selective waste collection systems).

To prevent any damage to the environment or human health, separate these products from other types of waste and recycle them correctly. This will help promote the sustainable use of material resources.

Household users should contact the retailer that they purchased the product from or the relevant local authorities to find out how and where they can recycle this product safely, without harming the environment.

Business users should contact their supplier and consult the terms and conditions of the purchase agreement. This product and its electronic accessories should not be disposed of with other waste materials such as the box and non-electronic materials.

APPENDIX F: Declaration of Conformity

Mundo Reader, S.L.
Pol. Ind. Európolis
Calle Sofía, 10
28232 - Las Rozas - Madrid (España)
Tel. +34 91 787 58 59
Corporate tax ID: B85991941
Made in China

Declares that this tablet:

bq Edison 3

complies with the provisions of Directive 1999/5/EC on Radio and Telecommunications Terminal Equipment (R&TTE), Directive 2006/95/EC on Electrical Safety for Low Voltage Equipment, and Directive 2004/108/EC on Electromagnetic Compatibility, in addition to the following harmonised standards:

EN 60950-1/A2:2013, EN 62311: 2008, EN 62479: 2010, EN 50566: 2013, EN 301 489-1 V1.9.2 , EN 301 489-17 V2.2.1, EN 55022:2010, EN 55024:2010, EN 61000-3-2/A2:2009, EN 61000-3-3:2008, EN 300 328 V1.8.1, EN 62209: 2010, EN 62209-2: 2010 , EN301489-3 V1.6.1, EN300440-2 V1.4.1, EN 301893 V 1.7.1, EN 55013: 2013, EN 55020: 2007/A11: 2011, EN 55020: 2007/A11:2011.

You can request a copy of the Declaration of Conformity by writing to the address above.

Madrid, May de 2014.



Alberto Méndez Peydró
CEO

CE 0168

Mundo Reader, S.L.
Pol. Ind. Európolis
Calle Sofía, 10
28232 - Las Rozas - Madrid (España)
Tel. +34 91 787 58 59
Corporate tax ID: B85991941
Made in China

Declares that this tablet:

Edison 3 3G

complies with the provisions of Directive 1999/5/EC on Radio and Telecommunications Terminal Equipment (R&TTE), Directive 2006/95/EC on Electrical Safety for Low Voltage Equipment, and Directive 2004/108/EC on Electromagnetic Compatibility, in addition to the following harmonised standards:

EN 301489-1 V1.9.2, EN301489-3 V1.6.1, EN 301489-7 V1.3.1, EN301489-17 V2.2.1, EN 301489-24 V1.5.1, EN62479: 2010, EN 62311: 2008, EN 301908-1 V6.2.1, EN301 908-2 V5.4.1, EN 301511 V9.0.2, EN 300328 V1.8.1, EN300440-2 V1.4.1, EN60950-1/A2:2013, EN 50566: 2013, EN 62209-2: 2010, EN 55022:2010/AC:2011, EN 55024: 2010, EN 55013: 2013, EN 55020: 2007/A11: 2011.

You can request a copy of the Declaration of Conformity by writing to the address above.

Madrid, November de 2014.



Alberto Méndez Peydró
CEO

CE 0168

Firmware version

bq Edison 3: 1.2.0_20141208-1110

bq Edison 3 3G: 1.1.0_20141128-0857



www.bq.com
www.mibqyyo.com